



NOTES:
 WOOD SPECIES ABBREVIATIONS
 AC = AMERICAN CHESTNUT
 SYP = SOUTHERN YELLOW PINE
 <SL> INDICATES SLOPING MEMBER.
 PROVIDE SHORING FOR BALCONY TRUSS AT SOUTH WALL PRIOR TO REMOVAL & RECONSTRUCTION OF SOUTH WALL PANELS.
 ESTIMATED TRUSS SHORING LOADS:
 DL: 12 PSF
 LL: 25 PSF
 SEE S1.1 FOR DESIGN PARAMETERS.

1 BALCONY FRAMING ON SECOND FLOOR PLAN
 SCALE: 1/4" = 1'-0"